

veito

EN User's Manual

LT Naudojimo Instrukcija



CH1800 XE

Carbon Infrared Heater

Infraaudonųjų Spindulių Šildytuvas Su Anglimi

Carbon Infrared Heater

- Thank you for purchasing Veito Carbon Infrared Heater. Please read the instructions thoroughly before using your heater.
- After reading the instructions, please keep it in a place accessible to all users.
- We cannot be liable for any damages caused by failure to observe these instructions.
- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way.

Safety Precautions

These precautions are designed for keeping users safe and preventing material damage. Be sure to read them and use the product correctly.

Read all instructions before installing and using this heater.

This heater is designed for use on a 220-240VAC 50/60Hz supply.

Use this heater only as described in this manual. Any other use not recommended by the manufacturer may cause fire, electric shock, or injury to persons.

This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

Children should be supervised to ensure that they do not play with the appliance.

The fireguard of this heater is intended to prevent direct access to heating elements and must be in place when the heater is in use.

The fireguard does not give full protection for young children and infirm persons.

Do not use the heater in areas where gasoline, paint, flammable liquids or highly combustible dusts are used or stored.

Ensure both plug and socket is clean and free from dust when using.

Regularly inspect the power cord and plug for wear or damage and do not operate the heater with a damaged cord, plug or loose socket or after the heater malfunctions, has been dropped or damaged in any manner.

To disconnect the heater from the power supply, turn the controls off, grip the plug and pull from the power socket. Never pull by the cord. Never touch the plug with wet or moist hands.

Do not kink or place the main power lead under heavy objects. Do not allow the supply cord to sit or hang in front of the heater while in use.

Do not overload the dedicated power socket with other equipment. Do not use an extension cord with this heater.

The heater must not be located immediately below a socket outlet or connection box and ensure that the unit is properly earthed through the mains power circuit.

Keep combustible materials such as furniture, pillows, bedding, papers, clothes and curtains at least 1.5m from the front of the heater and keep them away from the sides and rear.

Do not use the heater if the heating element is cracked or broken.

Never put hands or objects into the main body of the product. Never touch it immediately after use. Always disconnect the heater from the electricity supply and allow it to cool before adjusting the position or attempting to work on it.

Never place combustible objects on the product such as vinyl and plastic items.

Do not use this heater in the immediate surroundings of a bath, a shower, or a swimming pool.

Extreme care should be taken whenever the heater is left operating and unattended.

Never use the heater while sleeping.

Introduction

The Veito Carbon Infrared heater produces instant and comfortable heat like the sun. These robust and weatherproof heaters are designed for domestic and commercial heating applications.

Model	CH1800 XE
Heating Capacity (BTU/h)	7500
Maximum Power (W)	1700
Space for use (m ²)	20
Power Supply	AC 220-240V 50/60 Hz
Dimensions (mm) (WxLxH)	80X170x820
Product Weight (kg)	2.1
Controlling method	Level Control
Controlling function	2 Levels
Safety device	Tilt Sensor

Precautions for Installations

Never install the heater on a combustible surface. Do not use the unit on unstable or unsafe surfaces.

Install the product at places that are visible to people.

Do not install at places with high temperature.

Keep packaging parts because they are necessary in maintaining the heater for a long time.

Installation



Assemble the two parts of the base.



Insert the plastic connection part onto the aluminum profile.



Place the aluminum profile into the place on the base and push it on a level until it sounds 'click'.



Assemble the product stand with the product. Tighten the connection nut adequately as to secure the heater in position. You will re-adjust this height later.

Always leave a clear space of at least 0.5m from the left and right of the unit. The unit must also have at least 1.5m clear space above it. Never put any obstacles nearer than 1.5m to the front of the unit.

Use the unit in places with easy access to power sockets and that are well ventilated.

Never use connecting terminals in the power lead. Always directly connect the unit to the power.

Put plug into specific outlet for 220-240VAC 50/60Hz with earth terminal.

Configuration

1-Plastic Body

2-Base Reflector

3-Aluminium Body

4-Rear Reflector

5-Safety Grille

6-Carbon Filament

7-Control Knob

8-Aluminum Profile


9-Plastic Base

10-Carry Handle

11-Fixing Plastic

12-Fixing Nut

13-Power Cord



Operation and Stop


The appliance is not to be used by children or persons with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction.

- 1- Start operation by using Control Knob switch.
- 2- Heater is turned on and operation is started.
- 3- Use Control Knob switch to stop.

When the heater is knocked over, it will automatically shut down.

Electrical Circuit

1. Control Knob
2. Carbon Filament
3. Power Cord
4. Yellow-Green (E)
5. Brown (N)
6. Blue (L)
7. Tilt Sensor



Cleaning and Maintenance

Handle heater when it is completely cooled down and power is cut off.

If the heater has collected dust or dirt inside the unit or around the elements, have the unit cleaned by a qualified service agent. Do not operate the heater in this condition.

Do not attempt to open the case of the heater at any time; there are no customer serviceable parts inside.

Do not use powerful abrasive or solvent cleaning fluids when cleaning the heater as they may damage the plastic parts. Use only a clean, dry cloth to clean the external surfaces of the heater only.

Cleaning and user maintenance shall not be made by children without supervision.

Do not touch the heating element with bare fingers, as residue from your hand could affect the life of the lamp. If it is accidentally touched, remove the finger marks with a soft cloth moistened with methylated spirit or alcohol.

Ensure main body is clean and dry.

Cover the heater with the covering supplied when you purchased the unit. Keep it in a well-ventilated dry place.

Infraraudonųjų spindulių šildytuvas su anglimi

- Dėkojame, kad įsigijote Veito infraraudonųjų spindulių šildytuvą su anglimi. Prieš pradėdami šildytuvą naudoti, įdėmiai perskaitykite instrukciją.
- Perskaitę instrukciją, pasidėkite ją į tokią vietą, kur ją galėtumėte lengvai rasti visi naudotojai.
- Negalime prisiimti atsakomybės už žalą, atsiradusią dėl šių instrukcijų nesilaikymo.
- Šį prietaisą gali naudoti ir vaikai nuo 8 metų amžiaus bei asmenys, kurių fiziniai, jutiminiai arba protiniai gebėjimai yra nusilpę, kurie turi mažai patirties ir žinių, jei juos prižiūri ir nurodymus dėl prietaiso naudojimo duoda už jų saugumą atsakingas asmuo.

Saugumo nurodymai

Šie nurodymai skirti tam, kad prietaiso naudotojai būtų saugūs ir išvengtų materialinės žalos.

Būtina perskaitykite šiuos nurodymus ir naudokite gaminį tinkamai.

Prieš įrengdami ir naudodami šildytuvą, perskaitykite visą instrukciją.

Šį šildytuvą galima naudoti esant 220-240VAC 50/60Hz maitinimui.

Naudokite šį šildytuvą tik taip, kaip aprašyta šioje instrukcijoje. Naudodami prietaisą kitaip nei aprašyta, galite sukelti gaisrą, patirti elektros šoką ar susižeisti.

Šio prietaiso negalima naudoti asmenims (tame tarpe ir vaikams), kurių fiziniai, jutiminiai ar protiniai gebėjimai yra nusilpę, kurie turi per mažai patirties ar žinių, nebent juos prižiūri ir nurodymus dėl prietaiso naudojimo duoda už jų saugumą atsakingas asmuo.

Vaikus reikia prižiūrėti, kad su prietaisu jie nežaistų.

Šildytuve yra įrengta apsauga nuo gaisro, kuri saugo nuo tiesioginio priėjimo prie kaitinimo elementų, todėl ši apsauga visada turi būti savo vietoje.

Apsauga nuo gaisro nesuteikia visiškos apsaugos mažiems vaikams ir netvirtiems asmenims.

Nenaudokite šildytuvo, kur laikomi ar naudojami dažai, benzinas, degūs skysčiai ar ypač degios dulkės.

Pasirūpinkite, kad naudojimo metu kištukas ir maitinimo laidas būtų švarūs.

Reguliariai tikrinkite maitinimo laidą ir kištuką, ar jie nenusidėvėję ir nepažeisti. Nenaudokite šildytuvo, jei jo laidas ar kištukas pažeisti, jei maitinimo lizdas kliba ar jei pastebite kitokių sutrikimų. Nenaudokite prietaiso, jei jis buvo nukritęs ar yra pažeistas koku nors kitu būdu.

Norėdami išjungti šildytuvą iš maitinimo tinklo, išjunkite jį ir ištraukite iš maitinimo tinklo suimdami už kištuko. Niekada netraukite už laido. Niekada nelieskite kištuko drėgnomis ar šlapiomis rankomis.

Nesupainiokite laido ir nedėkite ant jo sunkių daiktų. Stebėkite, kad naudojant šildytuvą, laidas nekabėtų jo priekyje.

Neperkaukite maitinimo tinklo kitais prietaisais. Šildytuvo nenaudokite su prailginimo laidu.

Šildytuvo negalima laikyti tiesiai po maitinimo lizdu ar žemiau prijungimo dėžės.

Degias medžiagas, pavyzdžiui baldus, pagalves, lovatieses, popierius, drabužius ir užuolaidas, laikykite bent 1,5 m atstumus nuo šildytuvo iš visų pusių.

Nenaudokite šildytuvo, jei kaitinimo elementas yra įskilęs ar lūžęs.

Nekiškite rankų ar daiktų į gaminio korpusą. Nelieskite jo iš karto po naudojimo. Prieš reguliuodami šildytuvo padėtį ar atlikdami kokius nors kitus darbus, išjunkite jį iš maitinimo tinklo ir leiskite atvėsti.

Ant gaminio niekada nedėkite degių medžiagų, pavyzdžiui, vinilo ar plastikinių dalių.

Nenaudokite šildytuvo netoli vonios, dušo ar baseino.

Būkite ypač atsargūs ir atidūs, kai paliekate veikiantį prietaisą be priežiūros.

Niekada nenaudokite šildytuvo miegodami.

Įžanga

Veito infraraudonųjų spindulių šildytuvai su anglimi šildo greitai ir patogiai, kaip saulė.

Šie tvirti ir vandeniui atsparūs šildytuvai tinka naudoti ir buitinei, ir komercinei paskirčiai, tiek viduje, tiek lauke.

Modelis	CH1800 XE
Šildymo galingumas (BTU/val.)	7500
Didžiausias galingumas (W)	1700
Šildomos erdvės plotas (m ²)	20
Maitinimo tiekimas	AC 220-240V 50/60 Hz
Išmatavimai (mm) (plotis x ilgis x aukštis)	80X170x820
Gaminio svoris (kg)	2.1
Valdymo būdas	lygių reguliavimas
Valdymo funkcijos	2 lygiai
Apsauginis mechanizmas	posvyrio jutiklis

Įspėjimai dėl įrengimo

Niekada neįrenkite šildytuvo ant degaus paviršiaus. Nenaudokite prietaiso ant nestabilių ir nesaugių paviršių.

Įrenkite šildytuvą tokiose vietose, kurios yra matomos žmonėms.

Neįrenkite šildytuvo vietose, kur aukšta temperatūra.

Pasilikite pakuotės medžiagas, nes jų gali prireikti prietaiso priežiūrai.

Įrengimas



Surinkite dvi pagrindo dalis.



Uždėkite aliuminio profilį į vietą ant prietaiso pagrindo ir įstumkite jį taip, kad užsifikuotų ir pasigirstų spragtelėjimas.



Ant aliuminio profilio uždėkite plastikines sujungimo dalis.



Surinkite gaminio stovą ir prietaisą. Priveržkite prijungimo veržlę taip, kad šildytuvas būtų pritvirtintas tinkamoje padėtyje. Aukštį bus galima sureguliuoti vėliau.

Visada palikite bent 0,5 cm tuščios vietos iš prietaiso dešinės ir kairės pusių. Virš prietaiso reikia palikti bent 1,5 m tuščio ploto. Arčiau nei 1,5 m atstumu iki prietaiso negali būti jokių kliūčių.

Šildytuvą naudokite tokiose vietose, kur lengva prieiti prie maitinimo tinklo, ir kurios yra gerai vėdinamos.

Niekada nenaudokite terminalų laidui prijungti. Prietaisą visada junkite tiesiai į maitinimo tinklą.

Kištuką junkite į specialų maitinimo lizdą su žemintu terminalu, kurio maitinimo tiekimas 220-240 VAC 50/60Hz.

Dalys:

1-Plastikinis korpusas

2-Pagrindo reflektorius

3-Aliuminis korpusas

4-Galinis reflektorius

5-Apsauginės grotelės

6-Anglies pluoštas

7-Valdymo jungiklis

8-Aluminis profilis


9-Plastikinis pagrindas

10-Rankena prietaisui nešti

11-Tvirtinimo priedai (plastikiniai)

12-Tvirtinimo veržlės

13-Maitinimo laidas



Veikimas ir sustabdymas


Prietaiso negalima naudoti vaikams ir asmenims, kurių fiziniai, jutiminiai ir protiniai gebėjimai yra nusilpę, kurie turi per mažai patirties ir žinių, nebent juos prižiūri ir nurodymus jiems duoda už jų saugumą atsakingas asmuo.

- 1- Valdymo jungikliu šildytuvą įjunkite
- 2- Šildytuvas įsijungia ir pradeda veikti.
- 3- Valdymo jungikliu šildytuvą išjunkite.

Jei šildytuvas apvirsta, jis išsijungia automatiškai.

Elektros schema

1. Valdymo mygtukas
2. Anglies pluoštas
3. Maitinimo laidas
4. Geltona-žalia (E)
5. Ruda (N)
6. Mėlyna (L)
7. Posvyrio jutiklis



Valymas ir priežiūra

- Prieš atlikdami kokius nors darbus su šildytuvu, visada išjunkite šildytuvą iš maitinimo tinklo ir leiskite jam atvėsti.
- Jei į šildytuvo vidų, aplink kaitinimo elementą prisirinko dulkių ar purvo, prietaisą išvalyti turėtų kvalifikuotas paslaugų teikėjas. Tokios būklės prietaiso nenaudokite.
- Nemėginkite atidaryti prietaiso dėklo; viduje nėra jokių dalių, kurioms būtų reikalinga techninė priežiūra.
- Nenaudokite aštrių valymo priemonių ar tirpiklių prietaisui valyti, nes galite pažeisti plastikines prietaiso dalis. Valydami prietaiso išorę, naudokite drėgną audeklą.
- Vaikams negalima atlikti prietaiso valymo ir priežiūros darbų, jei jų niekas neprižiūri.
- Neliesite kaitinimo elementų nuogomis rankomis, nes likučiai nuo jūsų rankų gali turėti poveikio lempai. Jei atsitiktinai ją palietėte, nuvalykite pirštų antspaudus metilo spiritu ar alkoholiu sudrėkintu, minkštu audeklu.
- Pasirūpinkite, kad prietaiso korpusas būtų sausas ir švarus.
- Uždenkite šildytuvą pirkimo metu pateikta danga. Laikykite šildytuvą gerai vėdinamoje vietoje.

veito

veito

veito

www.veito.com

