

Imus



| | |
|-------------------------------|------------------|
| Bedienungsanleitung | DE 2-5 |
| Brugervejledning | DK 6-9 |
| Instrucciones de Uso | ES 10 -13 |
| Notice d'utilisation | FR 14-17 |
| Käyttöohjeet | FI 18-21 |
| Istruzioni per l'uso | IT 22-25 |
| Handleiding | NL 26-29 |
| Bruksanvisning | NO 30-33 |
| Instruções de Uso | PT 34-37 |
| User guide | UK 38-41 |
| Bruksanvisning | SE 42-45 |
| Instrukcje użytkowania | PL 46-49 |
| Uporabniški priročnik | SLO 50-53 |

Instructions for use


Imus

Product specifications

Freestanding infrared heater.

| | |
|---------------------------------|-----------------|
| Height: | 67,2 cm |
| Width: | Ø20 cm |
| Power source AC: | 230V AC ~ 50 HZ |
| Power consumption: | 0,55 kW |
| Protection class: | IP 44 |
| Use Imus at temperatures below: | 20 °C |

- 1: On/Off switch
- 2: Heat protective grid
- 3: Foot
- 4: Ventilation holes
- 5: Handle





Side view

Imus is designed to heat two persons sitting on either side of a table. The optimum heat is achieved by placing Imus at the middle below the table. It will take about 1 minute from the time you switch on Imus until you feel the heat. To get the most out of Imus, you should position yourself in such a way that you get heat on the inside of both of your legs so that your body gets optimal utilisation of the heat. Press the On/Off switch (1) to turn off the product if you do not require further heat.


Read the instructions before use.

Keep the manual handy for any questions of future use of your product.

The product is designed and manufactured in compliance with European standards: CE, RoHS.

The product complies with the essential requirements of the Directives: EN 60335-2-30:2009, EN 60335-1:2012.

Warning

- Use the heater only on flat and stable ground.
- Do not cover the product or the heater's grill. (2),(4),(5) 
- Do not use under a table with a tablecloth that extends more than 4 cm of the table edge.
- Do not use a blanket while using the heater, as this may block the heater.
- Do not place bags, rugs or other objects in such a way that they block the grill. (2)
- Do not use the heater close to curtains and other combustible materials.
- Required space between bottom of the table and the top of the heater is 5 cm.
- Do not insert foreign objects into the heat source behind the grill. (2),(4)
- Connect the product only to outlets with earth (GND).
- Do not place the heater directly below a socket outlet.
- Do not use the heater in the immediate surroundings of a bath, a shower or a swimming pool.
- Always take the product indoors after use, and let the product cool off before packing it away
- Do not use this heater outdoor during bad weather like rain, storm or snow.

- Do not use this heater with a programmer, timer or any other device that switches the heater on automatically, since a fire risk exists if the heater is covered or positioned incorrectly.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capacity unless they are supervised and instructed by a person who is responsible for their safety.
- **RISK OF LOSS OF LIFE AND ACCIDENT TO INFANTS AND CHILDREN!**
Never leave children unsupervised with the packaging materials or the product. There is a risk of suffocation and loss of life from electric shock.

Maintenance and cleaning

- Disconnect the plug from the socket before cleaning or when the product is not in use for prolonged periods of time.
- Do not clean the product until 60 minutes after it is turned off.
- When cleaning, do not spray cleaners or water directly into the product.
- Apply the cleaner on a cloth and wipe the product.
- For cleaning of reflector plate, please remove the grills. Clean the reflector plate with a rag with glass cleaner, please **DO NOT TOUCH** the lamp with fingers or the cloth.
- For cleaning of the grills, please remove the grills. Clean the grills with a cloth with glass cleaner.
- Regular maintenance of the product is recommended, as this will prolong the product's service life and appearance (in coastal areas, the product should be cleaned more frequently, due to atmospheric salinity).
- Regularly check the cord for damages and ensure that the plug is clean.
- If the power cord, lamp or other electrical parts need replacing, this must be done only by a qualified professional.

Troubleshooting

Follow the troubleshooting steps listed below:

- Make sure the power cord is connected correctly.
- Check the cable for any ruptures.
- Make sure the On/ Off switch has been pressed.
- Check whether the bulb has blown.
- If the product is turned off due to overheating caused by improper use (overheat sensor), the product must be disconnected from the socket outlet and cool off. Check the product for defects after 30 minutes of cooling. If there are no visible defects, try to reconnect the product again.

Please contact the place of purchase if this did not solve your problem.

Disposal



European directive 2002/96/EC on Electrical and Electronic Equipment Waste (WEEE), requires that old household appliances are not thrown into the normal municipal waste stream. The appliances should be collected separately to maximize the recovery and recycling of materials and reduce the impact on human health and the environment. The symbol of the “crossed off dustbin” is stamped on the product to recall the obligations of the separate collection. Consumers should contact their dealer or local authorities regarding the procedure to be followed for the removal of their product.

Warranty

The product warranty is pursuant to the Danish Sale of Goods Act. The warranty period starts on the day the product was purchased. Small defects and minor cosmetic flaws that do not affect use of the product or decrease the value of the product are not covered by the warranty. The warranty must be proved by presenting an original receipt showing the purchase date and product name. Warranty repairs must be carried out by a MENSA HEATING Authorized Service Centre. The product should only be used for private.

Warranty management

A defective product must be returned to the place of purchase along with a valid receipt. If the product becomes defective during the warranty period, the product must be returned to the place of purchase. Here, warranty-related repairs will be carried out on the product, if the defect pertains to the product or the production faults. Defects in the product will be tried rectified by repair or replacement of parts. In case of exchange of the product, the may occur differences in hue or model design compared to the purchased product.

Warranty disclaimer

Damage or defects resulting from neglect or improper use of the product is not covered by the warranty. Damage or defects resulting from the use of unoriginal replacement parts or unoriginal enhancements is not covered by warranty. The warranty does not cover force majeure such as lightning, flood, fire or damage occurred during transport. Warranty cover will be void, if the product's serial number has been changed, if any modifications have been made or if a repair has been attempted by any unauthorized service centre.

Download manual

You can always download your manual online at: www.mensaheating.com/FAQ

Imus



Scan this QR code to
download your digital manual

DE: Mensa Heating behält sich das Recht vor, Änderungen in den Anweisungen zu machen.

DK: Mensa Heating forbeholder sig retten til ændringer i brugsanvisningen.

ES: Mensa Heating se reserva el derecho de realizar cambios en las instrucciones.

FR: Mensa Heating se réserve le droit d'apporter des modifications dans les instructions.

FI: Mensa Heating pidättää oikeuden tehdä muutoksia ohjeita.

IT: Mensa Heating si riserva il diritto di apportare modifiche alle istruzioni.

NL: Mensa Heating behoudt zich het recht voor om wijzigingen in de instructies te maken.

NO: Mensa Heating forbeholder seg retten til å foreta endringer i instruksjonene.

PT: Mensa Heating reserva-se o direito de fazer alterações nas instruções.

UK: Mensa Heating reserves the right to make changes in the instructions.

SE: Mensa Heating förbehåller sig rätten att göra ändringar i instruktionerna.

PL: Zawartość instrukcji obsługi może ulec zmianie.

SLO: Mensa Heating si pridržuje pravico do sprememb v priročniku.